iShowDrive

(WIB5012)

User Manual

ABOUT THIS GUIDE

This guide explains the features and usage of the iShowDrive. The usage will involve a portable device of either a smartphone, tablet or computer. The iShowDrive is compatible with either the iOS, Android or Windows operating system.

SAFETY INSTRUCTIONS

Always read the safety instructions carefully:

- Keep this User Guide for future reference
- Keep this equipment away from humidity and fire

COPYRIGHT

The document contains proprietary information protected by copyright. All rights are reserved by iCIRROUND. No part of this guide may be reproduced in any form without prior written permission of iCIRROUND.

TRADEMARKS

iCIRROUND and the iCIRROUND logo are registered trademarks of iCIRROUND Inc. in Taiwan and other countries. All other brand and product names are trademarks or registered trademarks of their respective owners.

Table of Contents

1. Introduction 4
1.1 Features 4
1.2 Package Contents 5
1.3 System Compatibility 5
1.4 Drawing 5

2. Installation Guide 6
2.1 Wi-Fi Mode (iOS iShowDrive APP) 6
2-1-1 How to connect iShowDrive APP 6
2-1-2 Introduce iShowDrive APP 8
C-2 File edition 13
C-2-1 Select a file or multiple files to edit 13
C-2-2 Move files 14
C-2-3 Copy files 15
C-2-4 Delete files 15
C-2-5 Zip files 16
C-2-6 File encryption 18
C-2-7 To use Cloud Dropbox 21
C-3 Supported file formats 24
2-2 USB Mode 24
2-3 Wi-Fi Mode (Android iShowDrive APP) 24
2-3-1 How to connect iShowDrive APP 24
2-3-2 Introduce iShowDrive APP 26

C. File editions in iShowDrive / Local 31
C-1 Create a new folder 31
C-2 File edition 32
C-2-1 Move files 33
C-2-2 Copy files 33
C-2-3 Delete files 34
C-2-4 Rename file/folder name 34
C-2-5 Lock files 35
C-2-6 Unlock files 36
C-2-7 Zip files 36
C-2-8 UnZip files 37
C-2-9 To use Cloud Dropbox 38
C-3 Supported file formats 40

3. Specifications 40

4. Regulatory Compliance 41

1. Introduction

iShowDrive is a small-sized T-flash drive storage which designed with Wi-Fi 802.11/b/g/n technology. Users can wirelessly share files, videos from mobile phone, tablet or PC to the iShowDrive. It saves your time and achieve conveniently saving effects. iShowDrive comes an APP with friendly UI design for user easily edit like copy, paste or even allows users to use lock function to protect some important files. iShowDrive also can connect 10 portable devices or 5 devices to share video simultaneously. It is a small size design and allows you to carry and travel around.

1.1 Features

- Connect up to 10 portable device connections and 5 devices video streaming simultaneously
- Compatible with iOS and Android portable devices
- Smallest, lightest and portable Wi-Fi flash drive to carry around
- iShowDrive SSID name can be edited for easy identification
- Provide personal files encryption to protect personal privacy
- Support WPA2 password to provide Wi-Fi security
- Through Wi-Fi and iShowDrive APP to create a complete document management including copy/move/lock/create a new folder between portable device and iShowDrive
- Through iShowtDrive APP to connect with Dropbox for cloud share

- Through USB port to charge bulit-in Li-Polymer battery
- Support multi-formats
- Wi-Fi direct function allows iShowDrive to work without Internet
- Internet continuous
- Support concurrent mode to let you connect iShowDrive and through AP connection simultaneously
- Allow to play videos, music and photos on Apple TV directly
- One smartphone/pad- 5 iShowDrives connection simultaneously
- Expandable MicroSD storage capacity is up to Class 10 32G (options for SD card inside)

1.2 Package Contents

- iShowDrive x1
- Multi-language quick installation guide x1

1.3 System Compatibility

- iOS system
- Android

1.4 Drawing



Note: Wi-Fi LED lights blue: connect Wi-Fi

Power Charge LED lights red: power charging

2. Installation Guide

Note: Please insert the MicroSD memory card before use.

2.1 Wi-Fi Mode (iOS iShowDrive APP)

Note: Please download iShowDrive APP before use

2-1-1 How to connect iShowDrive APP

Connect “iShowDrive xxxxx” as Wi-Fi Network



Choose iShowDrive APP as below red mark



2-1-2 Introduce iShowDrive APP

Please click red mark setting icon for setting information for your reference. You can do the setting change.



Click below screen red mark to see iPhone setting information for your reference.



Click below screen for iShowDrive setting information for your reference, some of the setting functions can be changed.



A. Rename iShowDrive device name



B. Wi-Fi password security

Click and open “Security”, then enter the password to secure Wi-Fi



The device name for password is not allowed to use special character like ”, _.(!)..etc

Then APP screen is showed as above with red mark show lock icon.

(**Note: You must enter the same password to enter your iShowDrive)**

iPhone means the storage for mobile phone; and iShowDrive storage means the MicroSD storage

You can click below screen red mark to view “iPhone” folders/files, such as videos, pictures, music or other documents as below screen shows



Also, you can click below screen red mark to view “iShowDrive” folders/files, such as videos, pictures, music or other documents as below screen show

C. File editions in iShowDrive / iPhone

C-1 Create a new folder





Enter new folder name



C-2 File edition

C-2-1 Select a file or multiple files to edit

After you click the iShowDrive, please click “Edit” function as below red mark



Then it will come to below screen to let you choose which file to edit, the file you can select one or two or more for the editing as red mark shows.



or



Or click right arrow as below red mark to edit. When you click right arrow, it will show “Delete”, “Move”, “Copy”,”Rename”,”Cancel” as right screen shows for you to edit.



C-2-2 Move files

Choose the file to move as click “Move” as red mark shows or click right arrow to select “Move”, and then choose in which folder you want to move to



C-2-3 Copy files

Choose the file to copy as click “Copy” as red mark shows or click right arrow to select “Copy”, and then choose in which folder you want to copy to



C-2-4 Delete files

Choose the file to copy as click “Delete” as red mark shows or click right arrow to select “Delete”, and then choose in which folder you want to delete



Or you can slide leftward or rightward on the file/folder you want to delete





C-2-5 Zip files

Choose the file and click “Zip” as red mark shows then it start zipping.





When it compete zip, it will show the Zipped file type as below red mark shows



Unzip files

When you want to unzip, please click the zipped file to unzip directly, then it start unzipping



When it finish unzip, it will show unzip file as below screen red mark shows.



C-2-6 File encryption

Select the files and click this lock button

to lock



Enter password to lock



Locked file type



Unlock the file

Click this button

to unlock file



Enter the same password to unlock



C-2-7 To use Cloud Dropbox

When you only connect to iShowDrive and wish to link internet to connect Dropbox simultaneously, please click iShowDrive setting as below red mark shows.



Then you see Configure screen pop out, please select Wi-Fi network as below screen red mark shows

Then return to mobile phone setting to choose in “**Wi-Fi Setting**” to select the same Wi-Fi network



Then back to turn on iShowDrive APP, you will see the result as below red mark showed

Please click Dropbox as above screen black mark, it will pop out below screen.

Please enter your e-mail and password then you can use the dropbox function.

C-3 Supported file formats

File Viewers and Formats iOS	**Video format: 3gp, mov, mp4, m4v, rm, rmvb, avi, wmv, flv, mpg, mpv, mkv, ts** **Audio format: aac, aif, aiff, caf, wav, mp3, m4a** **Document format: doc, xls, ppt, docx, xlsx, pptx, rtf, vcf, key, numbers, Webarchive, htm, html, pdf ,txt,pages** **Image format: bmp, cur, gif, ico, jpg, jpeg, png, tif, tiff, xbm**

2-2 USB Mode

Switch to USB mode, and use as a pen drive



2-3 Wi-Fi Mode (Android iShowDrive APP)

Note: Please download iShowDrive APP before use

2-3-1 How to connect iShowDrive APP

Connect “iShowDrive xxxxx” as Wi-Fi Network



Choose iShowDrive APP



2-3-2 Introduce iShowDrive APP

Click setting as below red mark, it will come out setting information.



Click Local setting as below red mark, it will come out setting information



Click iShowDrive setting as below red mark, it will come out setting information





Note:If Dropbox is not yet connected with internet, it will show “Available Unknow”

A. Rename iShowDrive device name



B. Wi-Fi password security

Click ⚙ and click again for Device name to see the “Security” then enter the password to secure Wi-Fi





Then APP screen is showed as below with security as red mark shows

(**Note: You must enter the same password to enter your iShowDrive)**



* Local means the storage for mobile phone; and iShowDrive storage means the MicroSD storage

You can view the folders/files in “Local” such as videos, pictures, music or other documents as below chart red mark shows





You can view the folders/files in “iShowDrive” such as videos, pictures, music or other documents as below chart red mark shows





C. File editions in iShowDrive / Local

C-1 Create a new folder

Please click red mark as below and it will pop out “New Folder” screen, when entering new folder name and click ok, the new folder name will come out as below bottom screen of this page show.







C-2 File edition

Please soft click touch any folder, the edited function will pop out as red mark.



	It means Select all wished edited file, soft click touch ,it will show “All”
	It means Move wished edited file to other folder, soft touch ,it will show “Move”
	It means Copy wished edited file to other folder, soft touch ,it will show “Copy”
	It means Rename wished edited file name to another, soft touch ,it will show “Rename”
	It means Delete wished edited file/Document, soft touch ,it will show “Delete”
	It means ZIP or Lock wished edited folder/Document, soft touch ,it will show “ZIP” on folder level and it will show “ZIP / Lock” on Document

C-2-1 Move files

Choose the file to move, and then choose in which folder you want to move to



C-2-2 Copy files

Choose the file to copy, and then choose in which folder you want to copy to.



C-2-3 Delete files

Choose the file to delete, and then delete the items



C-2-4 Rename file/folder name

Choose the file to rename and click rename icon,then it will pop out the screen as below to let you rename.



C-2-5 Lock files

Choose lock function as red mark below, to lock the file you want to lock



File locked type will be finished as below.



C-2-6 Unlock files

Double click locked file and it will show unlock icon. Click the unlock icon and enter password, it will restore the file.



C-2-7 Zip files

Click the file and select zip icon to zip directly



C-2-8 UnZip files

Double Click zipped file will be unzip directly and show “Archive” as below screen red mark shows .



C-2-9 To use Cloud Dropbox

When iShowDrive connecting, click iShowDrive setting icon as red mark below.



Click Join Wi-Fi Network and select setting Wi-Fi network name as below



Then return back to Mobile Setting for Wi-Fi item to select original Wi-Fi network name again as below screens show.



And open iShowDrive APP for iShowDrive device will show network name as below red mark



When it comes the network name as above example Wi-Fi Tiva_TPlink, you can use Dropbox.

C-3 Supported file formats

File Viewers and Formats Android	**Video format: mp4, rmvb, avi,mpg** **Audio format: aac, wav, mp3** **Document format: doc, xls, ppt, pdf ,txt** **Image format: bmp, gif, jpg, png, tif**

3. Specifications

Name	**iShowDrive**	**Model**	**WIB5012**
Dimension	**75.2(L)*31.7(W)*16.4(H)mm**	**Weight**	**22g**
Storage Capacity	**Up to 32GB MicroSD memory card**	**System Power Source**	**USB mode:** **• Powered USB port** **Self-Power mode:** **• Internal Li-Polymer Battery**
Operation Mode Switch	**• USB mode** **• Wi-Fi mode (Concurrent mode)**	**Support device connections**	**Up to 10 device connections,**
File Viewers and Formats iOS		**Video format: 3gp, mov, mp4, m4v, rm, rmvb, avi, wmv, flv, mpg, mpv, mkv, ts** **Audio format: aac, aif, aiff, caf, wav, mp3, m4a** **Document format: doc, xls, ppt, docx, xlsx, pptx, rtf, vcf, key, numbers, Webarchive, htm, html, pdf ,txt,pages** **Image format: bmp, cur, gif, ico, jpg, jpeg, png, tif, tiff, xbm**	
File Viewers and Formats Android		**Video format: mp4, rmvb, avi,mpg**	

	Audio format: aac, wav, mp3 **Document format: doc, xls, ppt, pdf ,txt** **Image format: bmp, gif, jpg, png, tif**

Note: User is not allowed to remove battery by their own.

4. Regulatory Compliance

Factory: **Shen Shen Electronic Co., Ltd**
FCC Statement

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FOR PORTABLE DEVICE USAGE (<20cm from body/SAR needed)

Radiation Exposure Statement:

The product comply with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.



201-140223


RoHS